

Remove the door panel and peel back the door cover this will allow you to remove the door catch and modify the door wiring to gain extra wire slack.



Remove all the wire clips from the front of the door to gain the extra wire slack needed. You will have to cut and extend 2 cables for one of the door sensors as shown below.



VerticalBlinds.com

Make the wires to on a straight line and used "Zip ties" to secure the wires to the frame of the door.

