

Now that you have gain the extra wire slack, cut the factory wire boot in half and pull the extra wire slack out as shown on the right. Install the new VDI door bracket as show. Use the factory nuts.



One the bracket is securely installed on the door now you can install the second section of the now VDI hinge system.



Once the two pieces of the hinge and securely connected you can install the new VDI hinge on the car. Make sure to use a helper. Make sure that all the factory marks are on the correct position and the distance from the apron and the edge of the doors is the correct one.



Asked your helper to raise the door and installed the shock as shown on the image on the right.

