

Remove the door and cover the area around the factory hinges to protect the paint and the interior of the car. Use a power grinder to grind the top and bottom hinge as shown.



Use painters' tape on the apron around the top and bottom hinge as shown on the right to protect the paint. You will need to grind down the top and bottom hinge post as shown below



After grinding down the two-door hinge post place the new VDI hinge system against the two flat sections and mark the center of the holes. Try to get the holes as close to the center factory hinge post as possible. You will need to drill and tap one hole on at the



top and one hole at the bottom as shown.